

Technical data

Variable Speed Drive Type: Yaskawa A1000-Series

Type	Input			Output			
	Power	Fuse	Voltage	Current	I max for 60s	Power T=const.	Losses
CIMR-AC4	in kVA	in A	in V	in A	in A	in kW	in W
A0002FAA	1,4	6	400	1,8	2,7	0,37	61
A0004FAA	2,3	10	400	3,4	5,1	0,75	70
A0005FAA	4,3	10	400	4,8	7,2	1,50	87
A0007FAA	6,1	16	400	5,5	8,3	2,20	101
A0009FAA	8,1	20	400	7,2	10,8	3,00	108
A0011FAA	10,0	25	400	8,2	12,3	4,00	130
A0018FAA	14,6	36	400	14,8	22,2	5,50	221
A0023FAA	19,2	36	400	18,0	27,0	7,50	247
A0031FAA	28,4	50	400	24,0	36,5	11,00	323
A0038FAA	37,5	63	400	31,0	46,5	15,00	403
A0044FAA	39,3	80	400	39,0	59,0	18,50	509
A0058AAA	46,6	100	400	45,0	67,0	22,00	518
A0072AAA	53,0	125	400	60,0	90,0	30,00	701
A0088AAA	64,9	160	400	75,0	112,0	37,00	817
A0103AAA	78,6	160	400	91,0	136,0	45,00	1022
A0139AAA	96,0	225	400	112,0	168,0	55,00	1325
A0165AAA	129,9	250	400	150,0	225,0	75,00	1920
A0208AAA	155,0	300	400	180,0	270,0	90,00	2313
A0250AAA	189,0	350	400	216,0	324,0	110,0	3075
A0296AAA	227,0	450	400	260,0	390,0	132,0	3178
A0362AAA	274,0	600	400	304,0	456,0	160,0	4060
A0414AAA	316,0	700	400	370,0	555,0	185,0	4742
A0515AAA	375,0	900	400	450,0	675,0	220,0	5358
A0675AAA	508,0	1000	400	605,0	907,0	315,0	5875
	Weight	Dimensions	EMC-Filter				
			Name	Dimensions			
CIMR-AC4	in kg	W x H x D (mm)		WxHxD (mm)			
A0002FAA	3,2	140x260x147	**FB-4008A	140x301x50			
A0004FAA	3,2	140x260x147	**FB-4008A	140x301x50			
A0005FAA	3,2	140x260x147	**FB-4008A	140x301x50			
A0007FAA	3,4	140x260x164	**FB-4008A	140x301x50			
A0009FAA	3,5	140x260x164	**FB-4014A	140x301x50			
A0011FAA	3,5	140x260x164	**FB-4014A	140x301x50			
A0018FAA	3,9	140x260x167	**FB-4025A	140x301x50			
A0023FAA	3,9	140x260x167	**FB-4025A	140x301x50			
A0031FAA	5,4	180x300x167	**FB-4044A	140x301x50			
A0038FAA	5,7	180x300x187	**FB-4044A	140x301x50			
A0044FAA	8,3	220x350x197	FB-4060A	85x310x135			
A0058AAA	21,0	250x400x258	FB-4060A	85x310x135			
A0072AAA	25,0	275x450x258	FB-4072A	85x310x135			
A0088AAA	36,0	325x510x258	FB-4105A	95x325x150			
A0103AAA	36,0	325x510x258	FB-4105A	95x325x150			
A0139AAA	41,0	325x550x283	FB-4170A	130x440x181			
A0165AAA	42,0	325x550x283	FB-4170A	130x440x181			
A0208AAA	79,0	450x705x330	FB-4250A	155x525x220			
A0250AAA	96,0	500x800x350	FB-4250A	155x525x220			
A0296AAA	102,0	500x800x350	FB-4414A	300x500x130			
A0362AAA	107,0	500x800x350	FB-4414A	300x500x130			
A0414AAA	125,0	500x950x370	FB-4414A	300x500x130			
A0515AAA	216,0	670x1140x370	FB-4675A	300x500x130			
A0675AAA	221,0	670x1140x370	FB-4675A	300x500x130			
** Footprint-Filter							

Caution: The max. current of the compressor should be less than the rated current of the inverter.

General technical data:

	Name	Specification:
Input	Input Voltage	3-Phase 400V -15% to +10%
	Line frequency	50/60Hz +/- 5%
Output	Output frequency	0,01 to 400Hz Default setting: 30-60Hz
	Overload capacity	150% for 60s (HD)
Environment	Ambient temperature	-10°C to 50°C
	Humidity	< 95%, non condensating
	Storage temperature	-20°C to 60°C
	Altitude	Max. 1000m Output de-rating >1000m 1% per 100m max. 3000m max. 5,9m/s ²
Misc	Vibration	
	Safety standards	UL508C; EN954-1 Kat.3 IEC/EN61508 SIL2
	IP-Rate	IP20 or IP54 (22.0 to 75kW)

Variable Speed Drives YASKAWA A1000 - series



**Short manual:
A1000 with Software for
speed control of
compressors with
integrated compound
controller**

PED


Power Electronics Deutschland GmbH
Dieselstrasse 77
90441 Nürnberg

Tel.: +49 911 99 43 99 - 0

Fax.: +49 911 99 43 99 - 8

E-mail: info@ped-deutschland.de

L1 Standard refrigeration parameter	
-PRMSET- PRG Min. Druck P1-01 = -0.8 Bar (-100.0-100.0) "0.8 Bar" FWD	Description Parameter Number Range Default Change during while A1000 is running is permitted. Values highlighted in RED are different from default settings. ▶ Parameter-Description
-PRMSET- PRG Min. Press P1-01 = -0.8 Bar (-100.0-100.0) "0.8 Bar" FWD	Sensor lower level N The parameter P1-01 and P1-02 determine together the range of the pressure transducer. These settings are the reference to show the system pressure in real values in the display. Only transducers with the following specification can be used: Voltage range: 8 to 30V/DC Pressure range: -0,8 to 7,0 Bar. Other values on demand.
-PRMSET- PRG Max. Press P1-02 = 7.0 Bar (-100.0-100.0) "7.0 Bar" FWD	Sensor upper level N This parameter determines the setpoint for the suction pressure in the system.
-PRMSET- PRG Pressure Ref. P1-03 = 3.5 Bar (-100.0-100.0) "1.0 Bar" FWD	PRESSURE REFERENCE SETPOINT IN BAR Y Once the pressure level in the system is underneath the value in parameter P1-04 for the time set in parameter P1-05 the drive will switch automatically OFF. Example: According to factory settings the pressure must be for 10.0s below 1,5 Bar, then the drive is switching itself off.
-PRMSET- PRG AUTO-OFF Lvl P1-04 = 0.5 Bar (-50.0-50.0) "0.5 Bar" FWD	AUTO-OFF PRESSURE IN BAR Y Once the pressure exceeds the value set in P1-06 + P1-04 for the time set in parameter P1-07 the inverter will automatically switch on again. Example: P1-04 = 1,5Bar; P1-06 = 1,0Bar ON Pressure: 1,5Bar + 1,0Bar = 2,5Bar
-PRMSET- PRG AUTO-OFF time P1-05 = 0 sec (0-3000) "0sec" FWD	AUTO-OFF PRESSURE TIME IN SEC Y Once the pressure level in the system is underneath the value in parameter P1-04 for the time set in parameter P1-05 the drive will switch automatically OFF.
-PRMSET- PRG AUTO-ON Press P1-06 = 1.0 Bar (0.0-40.0) "1.0 Bar" FWD	AUTO-ON PRESSURE (HYSTERESIS) Y Once the pressure exceeds the value set in P1-06 + P1-04 for the time set in parameter P1-07 the inverter will automatically switch on again. Example: P1-04 = 1,5Bar; P1-06 = 1,0Bar ON Pressure: 1,5Bar + 1,0Bar = 2,5Bar
-PRMSET- PRG AUTO-ON time P1-07 = 20sec (0-3000) "20sec" FWD	AUTO-ON PRESSURE TIME IN SEC Y Once a digital input has been set to mode "80" the pressure reference will change in accordance to the setting in case this input becomes active. Example: P1-03 = 3,0Bar; P1-08 = -2,0Bar --> New reference: 1,0 Bar.
-PRMSET- PRG Add. 2. Ref P1-08 = 0.0Bar (-20.0-20.0) "0.0Bar" FWD	2. REFERENCE VIA DIGITAL INPUT Y Shows the system pressure and will be scaled in parameter P1-01 and P1-02 U7-02 System pressure U7-03 Pressure reference (P1-03)
-PRMSET- PRG System Press U7-02 = 1.5Bar U7-03 = 2.5Bar U7-04 = 0sec FWD	DISPLAY OF THE SYSTEM PRESSURE N Shows the system pressure and will be scaled in parameter P1-01 and P1-02 U7-02 System pressure U7-03 Pressure reference (P1-03)



R1 Standard-Wiring

Autotuning, Safety-, EMC-recommendations		R8
-PRMSET- PRG Min. Press P1-01 = -0.8 Bar (-100.0-100.0) "0.8 Bar" FWD	Description Parameter Number Range Default Change during while A1000 is running is permitted. Values highlighted in RED are different from default settings. ▶ Parameter-Description	
-A. Tune- PRG Auto-Tuning Mode Sel. Tun. mode T1-01 = 1 No rotate "0" FWD	Auto-Tuning Mode N 0=Rotating Autotuning (Vector-controlled) 1=Stationary Autotuning (Vector controlled) 2=Stationary Autotuning for line to line resistance. (Recommended) Choose mode and follow the menu..	
-A. Tune- PRG Motor Power T1-02 = 0.4kW (0.00-650.00) "0.40" FWD	Motor rated shaft power N Setup of the nameplate motor power in kW. This parameter generates the basis data to start with the autotuning function. Default values are depending on the inverter size.	
-A. Tune- PRG Motor Voltage T1-03 = 400.0VAC (0.0-510.0) "400.0VAC" FWD	Motor rated voltage N The motor rated voltage is needed to adjust the V/Hz curve. Example: Motor 230/400V Delta E1-13 = 230V; E1-06 = 50Hz; E1-04 = 87Hz; Max. frequency E1-06 = Motor rated frequency.	
-A. Tune- PRG Motor Current T1-04 = 1.0A (0.0-3.6) "1.0A" FWD	Motor rated current N With the setting of the motor rated current the A1000 could calculate a thermal model of the connected motor. This will prevent the motor to get overloaded (Fault: OL1)	
-A. Tune- PRG Base frequency T1-05 = 60.0Hz (0.0-400.0) "60.0Hz" FWD	Motor rated frequency N The base frequency of the motor determines the nameplate frequency of the connected motor.	
-A. Tune- PRG No of poles T1-06 = 4 (2-48) "4" FWD	Amount of Motor poles N The number of motor poles is used to input data for the autotuning function.	
-A. Tune- PRG Motor Speed T1-07 = 1750 (0-2400) "1750RPM" FWD	Motor rated speed N Text message after successful autotuning: "Tuning successful" Repeat procedure once autotuning was interrupted with fault message.	


Press "RUN" Key

RUN START >>>> GOAL

Text message after successful autotuning: "Tuning successful"
 Repeat procedure once autotuning was interrupted with fault message.

Safety and EMC - recommendations R8.1

Operation	The operation of the drive must be in accordance the safety regulations of the manual SIEPC710606 19A page 12. Commissioning and maintenance is only allowed throughout qualified and trained personal.
Power Off	After power Off the DC-bus voltage may remain up to 5 further minutes. Therefore before opening or servicing it is required to measure the DC-bus voltage to confirm a safe level.
Product-norms	All devices were tested through authorized institutions and are in accordance with the following standards: - EN61800-3:1996 - EN61800-3; A11:2000 All drives of the A1000 series are certified with: CE, UL, c-UL.
EMC-filter	For legal reasons it is required to meet the EMC standards. Therefore the EMC filters listed at page R2 must be used. If the EMC filters are correctly installed the drive will meet class "B" of the EN 55011. All filters are designed as footprint filters to be mounted underneath the A1000 series.
Motor cable (max. 50m)	It is highly recommended to use braided shield cables. The cable shield must be grounded on both sides. Wiring should be done as short as possible.
Control wiring (max. 50m)	All control cables should be shielded and must not be used together with power cables.
RCD Devices	The use of a standard earth leakage breaker (RCD) may not work, the breaker might trip before or not proper. It is highly recommended to choose a breaker specially designed for variable speed drives.



Autotuning, Safety and EMC R8

R7 Fault memory		
Fault:	Description	Cause / Action
GF	Ground fault	Current shorted to ground exceeded 50% motor current. Test of the A1000 without motor connected Check motor insulation
OC	Overcurrent	Output current of the A1000 is too high. Test with motor disconnected, Check motor insulation Eventually increase acceleration time in C1-01.
LF2	Current Imbalance	Output current imbalance. One motor phase at the output is missing, check wiring of the connected motor.
OU	Über-spannung	The DC-bus voltage has reached a value of 820V/DC. Increase the deceleration ramp rate. Check supply voltage (< 480V/AC +10%)
UJ1	DC-Bus too low	The DC-bus voltage is below 380V/DC. Check supply voltage and connections (> 350V/AC)
UJ2	Controlvolt. too low	The control voltage has reached a critical level. Check control terminals on short circuits or high consumption: Switch OFF and ON
UJ3	Soft charge circuitry	Fault while DC-bus capacitors were soft charged. Power OF and ON again, if problem still exist unit needs to be replaced.
PF	Input Phase loss	Ripple in the DC-bus too high (only if L8-05=1) Check supply voltage
LF	Output phase loss	Phase loss at the output (only if L8.07 = 1) Cable break at the motor cables, underload Check motor power and cabling
Oh	Over temperature	The heatsink temperature has exceeded 105°C. Check drive fan, ambient temperature and dust filter.
OL1	Motor overload	Motor overload due to the thermal model of the V1000 which has calculated an overload, ramp rates too short Check motor rated current in E2-01 V/Hz curve in E1-02 Check acceleration ramp rate in C1-01 evtl. too short Check deceleration ramp rate in C1-02 evtl. too short
OL2	A1000 overload	Variable speed drive overloaded Load too high, Ramp rates too short Check rated current in E2-01 V/Hz curve in E1-02 Check acceleration ramp rate in C1-01 evtl. too short Check deceleration ramp rate in C1-02 evtl. too short
UL3	A1000 underload	Torque below setting (only if L6-01 = 7 or 8) Belt monitoring Check mechanical setup
FbL	PID feedback loss	PID-feedback loss (only if B5-12 = 2) Check pressure transducer
EF3	External Fault 3	External fault at digital input S3 EF4 = S4; EF5 = S5; EF6 = S6; EF7 = S7 Check control wiring and find what has caused this.
CPF--	CPF XX Fault	Control board failure Power OF and ON again, if problem still exist unit needs to be replaced.

Alarm messages R6.1

Alarms shall protect the A1000 and do not cause tripping of the inverter. During alarm the display is blinking. After fixing the problem which has caused the alarm the V1000 returns automatically back to the status which was in case before the alarm.

Programming failures (OPE) R6.2		
OPE01	kVA failure	Failure A1000 sizing on parameter O2-04 Check input data of parameter O2-04 via display.
OPE02	Range exceeded	Failure A1000 sizing on parameter O2-04 Check input data of parameter O2-04 via display.
OPE03	Double Input	Some of the digital inputs were programmed with the same function or mode. Check digital inputs.

Autotuning Faults (Er) R6.3		
Er-01	Motor data fault	Failure data input, difference between motor power setting and motor current adjustment. Check motor data
Er-02	Alarm	Fault during autotuning. Check motor data, wiring and load, repeat autotuning

Failure copy function of the display R6.4		
PrE	Write protection	Failure write/read function from/to the display. Protection mode still active. Change Parameter O3-02 = Mode 1
LAE	Wrong device	Drive data are not correct. Check data in parameter o2-04.

R7.5 Message "COMP" Sequence

Comp Too many compressor Starts

Alarm message once the amount of starts according to parameter P2-05 were exceeded.
Remarks: This message will be reset automatically once the interval time is passed.
Example: P2-05= 10 --> 10 Starts per hour, a new start of any compressor in the system wouldle every 6 minutes. Once a start demand is required and 4 minutes are elapsed this message will appear for 2 minutes and after this time the compressor will be started the message disappears.

Caution: These messages are selected from the manual and are not complete.
Manual: YEG-SIEP C7 10606 27c

R7 Fault memory

Compound Controller Standard L2.1

The standard compound controller of the A1000 is always a compressor no1 which is speed controlled by the A1000 and up to 3 further compressors which can be switched ON and OFF by the inverter via contactors.
The compressors are time controlled activated, first compressor active will be that one with the lowest working hours..
Generally all compressors are named as follows:
+ Speed controlled compressor: Compressor 1
+ 1. Compound compressor: Compressor 2
+ 2. Compound compressor: Compressor 3
+ 3. Compound compressor: Compressor 4

	Sequence Compound ON	N	In case of further compressors in the Rack this parameter determines the sequence to switch the compound compressors ON and OFF: 0 --> Time controlled; 1st at variable speed drive and up to 3 further compressors switched ON/OFF depending on need and working hours. 1 --> LI-FO (See L3) 2 --> Auto-Change (See L4) 3 --> Twin Compressor (See L5)
--	-----------------------------	---	---

	Frequency to switch ON Compound Compressor	N	Once the output frequency has exceeded the value set in the parameter P2-01 for the time set in parameter P2-02 the A1000 will activate a digital output. Normally this parameter is set to max. output speed. In cases with compressors of different sizes, this function can be used to adjust the compound controller.
--	---	---	---

	Time to switch ON Compound Compressor	N	
--	--	---	--

	Level Compound Compressor OFF	N	Once the feedback value is below the value set in this parameter for the time set in parameter P2-04 the A1000 will de-activate the outputs for compressors no 2-4. Before the relevant digital output needs to be configured in Mode "40, 46 and 47". Output M1/M2: H2-01 Mode 40 Output M3/M4: H2-02 Mode 46 Output M5/M6: H2-03 Mode 47
--	--------------------------------------	---	---


	Compound Compressor OFF	N	
--	--------------------------------	---	--

	Max. Starts/h	N	Normally the amount of starts per hour is limited due to a possible thermal overload in case compressors are started direct on line (DOL). This parameter prevents the 2nd compressor. "0" = OFF
--	----------------------	---	--

	Countdown Timer for output relays	N	Once the conditions to switch the 2nd compressor ON or OFF are reached a down counter occurs in the display indicating the remaining time to switch ON or OFF in seconds.
--	--	---	---

	Compound Mode for the digital Outputs	N	Once a digital output is foreseen to activate a further compressor the relevant output must be configured to "40/46/47". h2-01 --> M1/M2; h2-02 --> M3/M4; h2-03 --> M5/M6
--	--	---	---

L3.2 Example compound controller



Compound controller Standard L2

L3.1 Compound Controller (LI-FO Sequence)

The standard compound controller of the A1000 is always a compressor no1 which is speed controlled by the A1000 and up to 3 further compressors which can be switched ON and OFF by the inverter via contactors.

The compressors will be activated and de-activated always in the same sequence. The compressor No2 (M1/M2) will be the first on, compressor No3 (M3/M4) will be the second and No4 (M5/M6) will be the last. The sequence to switch OFF is vice versa. In case less compressors are in the rack, the sequence is identical.

	Sequence Compound ON	In case of further compressors in the Rack this parameter determines the sequence to switch the compound compressors ON and OFF: 0 --> Time controlled (See L2) 1 --> LI-FO 2 --> Auto-Change (See L4) 3 --> Twin Compressor (See L5)
	Frequency to switch ON Compound Compressor	Once the output frequency has exceeded the value set in the parameter P2-01 for the time set in parameter P2-02 the A1000 will activate a digital output. Normally this parameter is set to max. output speed. In cases with compressors of different sizes, this function can be used to adjust the compound controller.
	Time to switch ON Compound Compressor	
	Level Compound Compressor OFF	Once the feedback value is below the value set in this parameter for the time set in parameter P2-04 the A1000 will de-activate the outputs for compressors no 2-4. Before the relevant digital output needs to be configured in Mode "40, 46 and 47". Output M1/M2: H2-01 Mode 40 Output M3/M4: H2-02 Mode 46 Output M5/M6: H2-03 Mode 47
	Time Compound Compressor OFF	
	Max. Starts/h	Normally the amount of starts per hour is limited due to a possible thermal overload in case compressors are started direct on line (DOL). This parameter prevents the 2nd compressor. "0" = OFF
	Countdown Timer for output relays	Once the conditions to switch the 2nd compressor ON or OFF are reached a down counter occurs in the display indicating the remaining time to switch ON or OFF in seconds.
	Compound Mode for the digital Outputs	Once a digital output is foreseen to activate a further compressor the relevant output must be configured to "40/46/47". h2-01 --> M1/M2; h2-02 --> M3/M4; h2-03 --> M5/M6

L3.2 Example compound controller LI-FO mode

Compound controller with 4 compressor
 Conditions:
 Compressor 1 speed controlled;
 Compressor 2, 3 and 4 DOL. Fixed sequence
Parameter:
 P5-01 = 1 (LI-FO - Sequence)
 P2-05 = 8 (Max. starts per hour)
 Once the amounts of starts per hour are exceeded the following message will be displayed: CALM4.
 The A1000 will not trip and continue to work.
 h2-01 = 40 --> The output relay M1/M2 is configured to start and stop the 2nd compressor.
 h2-02 = 46 --> The output relay M3/M4 is configured to start and stop the 3rd compressor.
 h2-03 = 47 --> The output relay M5/M6 is configured to start and stop the 4th compressor.
 P2-01 = 58Hz; Once the output speed is above 58Hz, the timer in P2-02 starts.
 P2-02 = 30s; Time to switch on the next compressor (2,3 or 4)

U7-04 = Shows the remaining time in seconds once timer P2-02 began to run.
 P2-03 = 2,5 Bar; Once the pressure is below this value, the timer in P2-04 starts.
 P2-04 = 10s; Time to switch OFF compressor no 2,3 or 4
 U7-04 = Shows the remaining time in seconds once the timer P2-04 began to run.

L3 Compound controller (LI-FO)

Monitor Screens II; Pressure Monitor U7-XX R6

	Shows the actual suction pressure and is determined by the value of analogue input A2 and the scaling of parameter P1-01 and P1-02. This screen is always shown after power ON if the A1000 is set to default mode.
	Shows the pressure reference in Bar and is set in Parameter P1-03. The default value is 1.0 Bar.
	Once the conditions to switch the compound compressors ON or OFF are fulfilled a countdown timer starts to run down to "0". Example: P2-01 = 58Hz and P2-02 = 30s. Once the output frequency exceeds 58Hz the countdown starts from 30s to 0s if the output frequency remains above 58Hz..
	Shows the remaining time for the next maintenance of the system and is depending on the settings of P3-03. Once the time is elapsed the message "CALM4" appears in the display. This is only an alarm message and does not cause a trip of the variable speed drive.
	Once a 0-10V pressure transducer is connected at analogue input A3, the condensing pressure will be displayed in this screen. The screen can be scaled with parameters P6-01 and P6-02.
	An internal PI-controller (P6-04 and P6-05) generates a signal for the condensing fan. This signal is based on the setting of the pressure reference in P6-03 and the actual condensing pressure from analogue input A3. This value will be passed on to the analogue output as a 0-10V signal if parameter h4-01 is set to "707" (Condensing pressure).
	Shows the actual running hours if parameter h2-01 was set to mode "40" and a compressor relay was connect to the terminals M1/M2.
	Shows the actual running hours if parameter h2-02 was set to mode "46" and a compressor relay was connect to the terminals M3/M4.
	Shows the actual running hours if parameter h2-03 was set to mode "47" and a compressor relay was connect to the terminals M5/M6.
	Shows the actual software version.

Error messages A1000 refrigeration software R6.2

	Once the feedback signal gets lost while the A1000 is running and emergency mode in parameter P2-10 is active (Mode 1), the A1000 will run at a fixed speed set in parameter P3-04 and show this message on the display.
	Once the feedback signal gets lost while the A1000 is running and emergency mode in parameter P2-10 is not active (Mode 0), the A1000 will trip and show this message on the display.
	In case more compressors are running in compound mode, the fault conditions of each compressor can be read via a digital input, see section "L8". If a compressor fault occurs during run (High pressure fault, motor thermal protection), the A1000 will de-activate this compressor and activate an alternative compressor.
	In case the system pressure drops by the value set in parameter P5-03 (Default 5.0 Bar) within the time set in P5-04 (default: 2.0s) a bursted tube could cause system damages. To prevent further problems the A1000 will switch OFF with error message "PrSSr". This function can be de-activated with parameter P5-04 set to 0.0.

Monitor Screens II

R6

R5 Monitor screens U1-XX		
Mode:	Description	Function:
01	Frequency reference	Shows the value of the frequency reference. This reference is not used in the refrigeration software. Min. unit: 0,01 Hz
02	Output frequency	Shows the current output frequency. Min. Unit: 0,01 Hz
03	Output current	Shows the output current. Unit: 0,01 A
06	Output voltage	Shows the momentary output voltage Min. Unit: 0,1 V
07	DC-Bus voltage	Shows the DC-Bus voltage UDC/√2=Input or supply voltage 565V/DC / 1,414 = 400V Uin
08	Output power	Shows the putput power in kW. Min. Unit: 0,1 KW
10	Input terminals status	U1-10 = Example see left side: S6 S5 S4 S3 S2 S1 Terminals S1 and S4 = Signal Rest = no Signal
11	Output terminals Status	U1-11 = Example see left side: P2 P1 MA Relay MA/MC = active PCPCMC P1/PC and P2/PC = not active
13	Level terminal A1	Shows the input level at analogue input A1. 0% --> 0V or -10V (according to h3-01) 100% --> 10V
14	Level terminal A2	Shows the input level at analogue input A2. 0% --> 0V; -10V or 4 mA (according to h3-09) 100% --> +10V or 20mA
15	Level terminal A3	Shows the input level at analogue input A3. 0% --> 0V; -10V (according to h3-05) 100% --> +10V

R5.1 Fault monitoring U2-XX		
01	Actual fault	Shows the failure code of the actual fault. Failure code according to table R9 No fault = NONE
02	Last fault	Shows the failure code of the last fault. Failure code according to table R9 No fault = "NONE"
03	Reference at last fault	Shows the reference speed while the drive was tripping last time.
04	Output frequency at last fault	Shows the output speed while the drive was tripping last time.
05	Output current at last fault	Shows the output current while the drive was tripping last time.
08	DC-Bus voltage at last fault	Shows the DC-Bus voltage while the drive was tripping last time.
11	Status Input terminals	U1-10 = Shows the status of the input terminals while the drive was tripping last time. S7 S6 S5 S4 S3 S2 S1
14	Running time at last fault	Shows the running time while the drive was tripping last time.

R5.2 Fault history U3-XX		
01	Failure code last fault	U3-02 failure code 2nd most recent fault U3-03 failure code 3rd most recent fault U3-XX
09	Failure code 9th most recent fault	U3-09 failure code 9th most recent fault U3-10 Operation time last fault U3-11 Operation time 2nd most recent fault
11	Operation time last fault	U3-12 Operation time 3rd most recent fault U3-XX
20	Operation time 9th most recent fault	U3-20 Operation time 9th most recent fault

Important:
The following failure codes will be not monitored in the fault history screens:
CPF00 Fault display communication
CPF01 Fault display communication
CPF03 EEPROM failure
UV1 Low voltage fault
UV2 Low voltage control supply

R5.3 Maintenance Monitor U4-XX		
01	Accumulated operation time	Shows the total operation time of the drive and can be reset with parameter o4-01.
02	Number of RUN commands	Displays the number of times the RUN command has been entered and can be reset with parameter O4-13.
08	heatsink temperature	Shows the heatsink temperature in °C.
13	Max. output current	Displays the max. current during RUN status.


This is only a selection from the Yaskawa manual YEG-SIEP C7 10606 27c of the screens mostly in use and does not demand any requirements for completeness.

Compound Controller ACC Auto-Change-Control L4.1

To ensure a balanced oil flow inside the refrigeration system with two compressors. Both compressors are controlled by the A1000, either with variable speed or direct on line. The A1000 changes automatically the compressor which will be driven by the inverter in the interval time set in parameter P5-02. On demand the second compressor will be added direct on line, controlled by the A1000. Particularly in winter time it may happen that there is always a demand for only one compressor, by changing over the compressor in fixed intervall times it will be prevented that compressor may start without oil inside.

	Sequence Compound ON	In case of further compressors in the Rack this parameter determines the sequence to switch the compound compressors ON and OFF: 0 --> Time controlled; 1st at variable speed drive and up to 3 further compressors switched ON/OFF depending on need and working hours. (See L2) 1 --> LI-FO (See L3) 2 --> Auto-Change 3 --> Twin Compressor (See L5)
	Frequency to switch ON Compound Compressor	Once the output frequency has exceeded the value set in the parameter P2-01 for the time set in parameter P2-02 the A1000 will activate a digital output. Normally this parameter is set to max. output speed. In cases with compressors of different sizes, this function can be used to adjust the compound controller.
	Time to switch ON Compound Compressor	
	Level Compound Compressor OFF	Once the feedback value is below the value set in this parameter for the time set in parameter P2-04 the A1000 will de-activate the outputs for compressors no 2-4. Before the relevant digital output needs to be configured in Mode "40, 46 and 47". Output M1/M2: H2-01 Mode 40 Output M3/M4: H2-02 Mode 46 Output M5/M6: H2-03 Mode 47
	Compound Compressor OFF	
	Max. Starts/h	Normally the amount of starts per hour is limited due to a possible thermal overload in case compressors are started direct on line (DOL). This parameter prevents the 2nd compressor. "0" = OFF
	Countdown Timer for output relays	Once the conditions to switch the 2nd compressor ON or OFF are reached a down counter occurs in the display indicating the remaining time to switch ON or OFF in seconds.
	Compound Mode for the digital Outputs	Once a digital output is foreseen to activate a further compressor the relevant output must be configured to "40/46/47". h2-01 --> M1/M2; h2-02 --> M3/M4; h2-03 --> M5/M6

Example compound controller ACC - Mode L4.2




Compound controller with 2 compressor
Conditions: ACC Mode
Compressor 1 speed controlled or DOL
Compressor 2 speed controlled or DOL
Parameter:
P5-01 = 2 (ACC)
P5-02 = 30min Intervall time
h2-01 = 40 --> The output relay M1/M2 is configured to change over between compressor no 1 and compressor no 2.
h2-02 = 46 --> The output relay M3/M4 is configured to start and stop the 1st compressor.
h2-03 = 47 --> The output relay M5/M6 is configured to start and stop the 2nd compressor.
P2-01 = 58Hz; Once the output speed is above 58Hz, the timer in P2-02 starts.
P2-02 = 30s; Time to switch on the second compressor DOL
U7-04 = Shows the remaining time in seconds once timer P2-02 began to run.
P2-03 = 2,5 Bar; Once the pressure is below this value, the timer in P2-04 starts.
P2-04 = 10s; Time to switch OFF compressor running DOL

L5.1 Compound Controller TCC Twin-Comp.-Control

To ensure a balanced oil flow inside the refrigeration system with two compressors. Both compressors are controlled by the A1000, either with variable speed or direct on line. The A1000 changes automatically the compressor which will be driven by the inverter in the interval time set in parameter P5-02. On demand the second compressor will be added direct on line, controlled by the A1000. Particularly in winter time it may happen that there is always a demand for only one compressor, by changing over the compressor in fixed interval times it will be prevented that compressor may start without oil inside.

	Sequence Compound ON	In case of further compressors in the Rack this parameter determines the sequence to switch the compound compressors ON and OFF: 0 --> Time controlled; 1st at variable speed drive and up to 3 further compressors switched ON/OFF depending on need and working hours. (See L2) 1 --> LI-FO (See L3) 2 --> Auto-Change (see L4) 3 --> Twin Compressor
	Frequency to switch ON Compound Compressor	Once the output frequency has exceeded the value set in the parameter P2-01 for the time set in parameter P2-02 the A1000 will activate a digital output. Normally this parameter is set to max. output speed. In cases with compressors of different sizes, this function can be used to adjust the compound controller.
	Time to switch ON Compound Compressor	Once the feedback value is below the value set in this parameter for the time set in parameter P2-04 the A1000 will de-activate the outputs for compressors no 2-4. Before the relevant digital output needs to be configured in Mode "40, 46 and 47". Output M1/M2: H2-01 Mode 40 Output M3/M4: H2-02 Mode 46
	Level Compound Compressor OFF	Normally the amount of starts per hour is limited due to a possible thermal overload in case compressors are started direct on line (DOL). This parameter prevents the 2nd compressor. "0" = OFF
	Compound Compressor OFF	Once the conditions to switch the 2nd compressor ON or OFF are reached a down counter occurs in the display indicating the remaining time to switch ON or OFF in seconds.
	Max. Starts/h	Once a digital output is foreseen to activate a further compressor the relevant output must be configured to "40/46/47". h2-01 --> M1/M2; h2-02 --> M3/M4;
	Countdown Timer for output relays	Once a digital output is foreseen to activate a further compressor the relevant output must be configured to "40/46/47". h2-01 --> M1/M2; h2-02 --> M3/M4;
	Compound Mode for the digital Outputs	Once a digital output is foreseen to activate a further compressor the relevant output must be configured to "40/46/47". h2-01 --> M1/M2; h2-02 --> M3/M4;

L5.2 Example compound controller TCC - Mode



Compound controller with 2 compressor

Conditions: ACC Mode
 Compressor 1 speed controlled
 Compressor 2 speed controlled

Parameter:

P5-01 = 3 (TCC)

P5-02 = 30min Intervall time

h2-02 = 40 --> The output relay M1/M2 is configured to start and stop the 1st compressor.

h2-03 = 46 --> The output relay M3/M4 is configured to start and stop the 2nd compressor.

P2-01 = 58Hz; Once the output speed is above 58Hz, the timer in P2-02 starts.

P2-02 = 30s; Time to switch on the second compressor DOL

U7-04 = Shows the remaining time in seconds once timer P2-02 began to run.

P2-03 = 2,5 Bar; Once the pressure is below this value, the timer in P2-04 starts.

P2-04 = 10s; Time to switch OFF compressor running DOL

Modes for In- and Outputs

R4

Modes digital inputs S3 to S8 (h1-01 - h1-08)

R4.1

Modes:	Description	Function:
03	Multi-step speed 1	The A1000 is running the motor with a fixed output frequency set in parameter d1-02 Default for input S5.
04	Multi-step speed 2	The A1000 is running the motor with a fixed output frequency set in parameter d1-03 Default for input S6.
05	Multi-step speed 3	The A1000 is running the motor with a fixed output frequency set in parameter d1-05
06	JOG-speed	The A1000 is running the motor with a fixed output frequency set in parameter d1-17. This frequency has got priority against other references.
08	Ext. base block n.o.	External base block (no), the drive output will be switched OFF once a signal occurs at a digital input. This will be indicated with a "bb" message in the display.
09	Ext. base block n.c.	External base block (nc), the drive output will be switched OFF once signal gets lost at a digital input. This will be indicated with a "bb" message in the display.
0F	Not used	This particular input is without function.
14	Fault RESET	On signal input the A1000 will be reset after it tripped, this mode is default for digital input S4. The cause for the trip must be fixed before reset will be activated.
15	Emergency-Stop	Signal input at a digital input with this mode will stop the motor with the ramp rate set in parameter C1-09.
19	PID-loop OFF	On signal input the A1000 will switch OFF the PID loop.
24	Ext. fault n.o.	On signal input the A1000 will tripp with fault message "EFX" (X=S3 bis S6). It needs a reset signal to restart.
25	Ext. fault n.c.	Once signal gets lost at a digital input of the A1000 it will tripp with fault message "EFX" (X=S3 bis S6). It needs a reset signal to restart.
2C	Ext. fault warning n.o.	On signal input the A1000 will indicate a warning message "EFX" (X=S3 bis S6) on the display. It will continue to run.
2D	Ext. fault warning n.c.	Once signal gets lost at a digital input of the V1000 it will indicate a warning message "EFX" (X=S3 bis S8) on the display.
35	PID-loop Invert	On signal the PID loop signal will be inverted.

Modes digital outputs 1 to 3 (h2-01 - h2-03)

R4.2

00	During Run	Closed: A run command is active or voltage is at the output. Default for output 2 (P1) =h2-02.
01	Zero speed	Closed: Output frequency is zero.
02	User set speed agree 1	Closed: Output speed equals the speed reference (plus or minus the hysteresis set in L4-02 (Band width)).
06	V1000 is ready	Closed: Drive ready. The drive is powered up, not in a fault state and in DRIVE mode.
0C	Frequency reference loss	Closed: Loss of the analogue frequency reference detected. Enable when L4-05 = 1.
0E	Fault	Closed: Fault occurred (other than CPF00 and CPF01)
10	Minor fault	Closed: An alarm is triggered.
20	oH pre alarm	Closed: Heatsink temperature exceeds parameter L8-02 value; Default: 95°C
37	During frequency output	Closed: Frequency is given to the output. Open: Operation stopped; baseblock; DC injection braking or initial excitation is performed.

Modes analogue input A2 (h3-10)

R4.3

02	2. reference	Once one of digital inputs S3 to S7 is programmed in mode 3, analogue input A2 will be used as reference frequency (Standard A1).
06	feedback for PID-loop	With this mode the analogue input A2 is used as a feedback source for the PID loop.

Modes analog outputs AM (h4-01)

R4.4

01	Frequency reference	Shows the actual frequency reference as a 0-10V signal, 10V = max.fFrequency.
02	Output frequency	Shows the actual output frequency as a 0-10V signa. 10V = max. frequency according to E1-04.
03	Output current	Shows the actual output current of the A1000. 10V = rated current of the A1000 Frequenzumrichter.
24	PID-feedback value	Shows the actual PID feedback signal. 10V = 100% feedback value.

This is only a selection from the Yaskawa manual YEG-SIEP C7 10606 27c of the screens mostly in use and does not demand any requirements for completeness.

L5 Compound controller TCC mode


Modes for In- and Outputs

R4

R5 Mostly used Standard-Parameter III

-PRMSET- PRG Reson. freq 1 D3-01 = 0.0Hz (0.0-400.0) "0.0 Hz"	Resonance-frequency 1	N	In order to avoid continuous operation at a speed that causes resonance in driven machinery, the A1000 can be programmed with 3 separate skip frequencies. This will not allow continued operation within specific frequency ranges. If the speed reference falls within a skip frequency dead band, the A1000 will clamp the frequency reference just below the dead band and only accelerate once the reference rises above the upper end of the dead band. The following conditions must be fulfilled: $d3 - 01 > d3 - 02 > d3 - 03$
-PRMSET- PRG Reson. freq 2 D3-02 = 0.0Hz (0.0-400.0) "0.0 Hz"	Resonance-frequency 2	N	
-PRMSET- PRG Reson. freq 3 D3-03 = 0.0Hz (0.0-400.0) "0.0 Hz"	Resonance-frequency 3	N	
-PRMSET- PRG Bandwidth D3-04 = 1.0Hz (0.0-20.0) "1.0 Hz"	Bandwidth Resonance-frequency	N	

R8.1 Example for a skip frequency



Oil-Reflow-, Crankcase Heater-function, Maintenance L6

Parameter Number:	Range min. max.	Default Setting Value:	Change during operation	Parameter-description
-------------------	-----------------	------------------------	-------------------------	-----------------------

Oil-Reflow-function L4.1

Time oil reflow in seconds
P2-06 0 300 300 N
Once the A1000 is running with an output frequency which is below the value set in parameter P2-07 for the time set in parameter P2-06 the oil-reflow function will become active.

Frequency Oil-Reflow in Hz
P2-07 0 400 35 N
Caution: Once the oil-reflow is active the user must ensure that all refrigeration load will be switched on to avoid tripping due to low system pressure.

Oil-reflow running time in seconds
P2-08 0 300 60 N
Once the oil reflow function is active the A1000 will accelerate the compressor to rated speed for the time set in this parameter.

Output relay MA/MC
h2-01 0 192 41 N
Mode "41" for the output relay will be used to switch on all refrigeration load in the system while the oil-reflow mode is active.

Oil-Reflow at start
P2-09 0 1 0 N
Once this function is active (Mode 1) the A1000 will run with rated speed for the time set in parameter P2-08 at every time it gets a start command.

Crankcase heater auto-mode L6.2

Caution: This function is only valid if the ambient temperatures of the A1000 and compressor are identical!

Temperature heater ON
P3-01 0 50 10 N
Normally every time a standard compressor will be stopped the crankcase heater will be activated. The V1000 series can read the heatsink temperature, in this mode the drive will activate the crankcase heater individually once the temperature is below the setting in P3-01. Parameter P3-02 is used for the time to check the heatsink temperature periodically. This will ensure that the heater will be active, only on demand.

Interval to check temperature
P3-02 0 600 15 N

Output relay MA/MB/MC
h2-01 0 192 42 N
Mode "42" for the output relay MA/MC secures that the oil reflow function will become active through the output relay of the drive. Alternative Optocouplers: H2-02 Output P1; H2-03 Output P2

Example crankcase heating with output P2 L6.3

Specification:
Activate the crankcase heater once the ambient temperature is below 20°C.

Parameter:
P3-02 = 20,0°C (Temperature)
P3-03 = 30,0 Min (Sample rate)
h2-03 = 42 (Mode)

Function:
+ Once the ambient temperature is below 20°C the crankcase heater will be activated at every standstill of the compressor.
+ The A1000 will be warmed up during operation, so the heatsink needs to cool down before measuring will start.
+ The setting of Parameter P3-02 to 30min. will ensure that the crankcase heater is ON for the first 30min, afterwards depending on the heatsink temperature the heater will be switched OFF if the temperature is still above 20°C. This will be checked every 30 minutes.

Caution: This function is only valid if the ambient temperature of A1000 and compressor is identical!
Because of the internal switch mode power supply of the A1000 the heatsink might be slightly warmer than the compressor.

Maintenance Counter
P3-03 0 300 100 N
Determines the maintenance interval. Once the running time exceeds this value the following message appears in the display: "Calm3 Maintenance required".
Max.: 30000h; Default: 10000h

Remarks: The A1000 will not trip, only a warning will be displayed.
In case this happens the counter could be reset by setting a new value for e.g. 10000h. The message / alarm will disappear.


R4 Mostly used Standard-Parameter III

Crankcase heating

L7.1 References via terminals

Parameter Number:	Range min. max.	Default Setting Value:	Change during operation	Parameter-description
P1-09	0 2	0	N	Reference via terminals

With short circuiting the terminals in accordance with the following chart the reference can be modified:
 Mode: 0 Reference = P1-03;
 1 Reference = A1; 2 Reference = terminals



Caution:
 All settings are made for a pressure transducer with the following specifications:
 Voltage range: 8-30V/DC; Signal: 4-20mA; Range: -0,8 to 7,0 Bar

Reference 3 via terminal S4	h1-04	0 9F	14	N	The wiring to set a reference via the digital inputs needs to be configured. Input: S4 Mode 5 = Reference 3
Reference 1 via terminal S5	h1-05	0 9F	3	N	The wiring to set a reference via the digital inputs needs to be configured. Input: S5 Mode 3 = Reference 1
Reference 2 via terminal S6	h1-06	0 9F	4	N	The wiring to set a reference via the digital inputs needs to be configured. Input: S6 Mode 4 = Reference 2

L7.2 Low Pressure Bypass at Start

Low pressure off level at "Start"	P1-10	-50 50	15	Y	At every start of the compressor the low pressure switch OFF level will be reduced for the time set in parameter P1-11.
Low pressure time at "Start"	P1-11	0 300	0	N	Determines the time were the low pressure OFF level at start is active. This function is not active once the value will be set to "0" in the parameter.

L7.3 Behaviour on power ON

Behaviour on power ON	P1-12	0 3	3	N	Determines the reaction of the drive on power on of the A1000: Mode 0: Low pressure function not active Mode 1: Start without delay Mode 2: Start with delay according to P1-07 Mode 3: Start depending on the pressure at P1-04
-----------------------	-------	-----	---	---	--

L7.4 Display indication after Power ON

With standard LCD display



Remark:
 Operation and Programming example at page L7

L7 Pressure reference via terminal

Mostly used Standard-Parameter II R2

Parameter Number:	Range min. max.	Default Setting Value:	Change during operation	Parameter-description	
Motor nameplate frequency	E1-06	0 400	60	N	Rated motor frequency and voltage, is needed to adjust the V/Hz curve. Example: 87Hz Operation:
Motor nameplate voltage	E1-13	0 510	400	N	Motor 230/400V; connected in Delta E1-04 = 87Hz max. Output frequency E1-05 = 400V max. Output voltage E1-06 = 50Hz Base frequency (Nameplate) E1-13 = 230V Motor rated voltage
Motor rated current	E2-01	0 999	0	N	With the input of the rated motor current the A1000 will calculate a thermal model of the connected motor to protect against overheating. If the compressor would run too long at low speed, it will trip with fault "OL1."
Number of motor poles	E2-04	2 48	4	N	Determines the amount of motor poles and is used as basic data to calculate the auto-tuning function..
Motor nameplate power	E2-11	0 999	0	N	Determines the motor shaftpower and is used as a basic data for the calculation of the autotuning function. Default values may differ due to the size of the variable speed drive.
Modes digital inputs S1 to S6	h1-01	0 78	0	N	The mode of the digital inputs S1 - S7 is selectable according to table R6.1. The default settings are: S1 = Start forward command (h1-01) S2 = Start reverse command (h1-02) S3 = 24 External fault (h1-03) S4 = 14 RESET (h1-04) S5 = 03 Multifrequency 1 (h1-05) S6 = 04 Multifrequency 2 (h1-06)
Modes digital outputs 1, 2, 3	h2-01	0 192	E	N	The digital outputs M1/M2, M3/M4, M5/M6 free selectable according to the table R4.2. The default values are: M1/M2 = "E"; Fault (h2-01) M3/M4 = "0"; During RUN (h2-02) M5/M6 = "2" Speed agree 1" (h2-03)
Modes digital outputs 1, 2, 3	h2-03	0 192	2	N	
Gain analogue Input A1	h3-03	0 100	100	J	Sets the level of the analogue input A1 when 10V is input at terminal A1. Parameter H3-10 determines the gain on analogue input A2 Range: -999,9 to 999,9
Bias analogue Input A1	h3-04	0 100	00	J	Sets the level of the analogue input A1 when 0V is input at terminal A1. Parameter H3-11 determines the bias for analogue input A2 Range: -999,9 to +999,9%
Modes for analogue Input A2	h3-10	0 31	b	N	This function determines the functions of analogue input A2 and can be selected with table R6.3. Parameter H3-02 determines the functions for analogue input A1.
Function analogue Output AM	h4-01	1 31	b	N	The function of the 0-10V analogue output FM is depending on the settings in accordance with the monitor screens at page R5. Range: 0 to 999.
Gain analogue output AM	h4-02	0 100	100	J	Determines the gain of the analogue output AM. Range: -999,9 to 999,9%
Bias analogue output AM	h4-03	0 100	0	J	Determines the bias (Offset) of the analogue output AM. Range: -999,9 to +999,9%
Power loss operation mode	L2-01	0 2	0	N	Determines the reaction of the A1000 on momentary power loss: 0 = Trips with fault: Uv1 (Undervoltage) 1 = Re-start depending on settings of L2-02 2 = Re-start as long CPU is active
Number of Autoreset starts	L5-01	0 10	0	N	Determines how often the A1000 will automatically reset the drive after it tripped with fault and will try to start again.
Fault reset interval time	L5-04	05 600	10	J	Once the A1000 trips with active autotuning function (L5-01) this parameter will set the time to wait until the start shall happen. The delay time for the re-start is given in seconds.
Function "STOP"-key	02-02	0 1	1	N	Once the Start/Stop control is given through the terminals the STOP can be set as follows: 0 = STOP-key is disabled 1 = STOP-key is enabled.
Mode copy function	03-01	0 3	0	N	This function has got the following modes: 0 = Normal operation 1 = READ from A1000 to Display 2 = WRITE from Display to A1000 3 = COMPARE
Activate copy function	03-02	0 1	0	N	Before using the copy function it must be activated. Mode 0 = Copy function not active Mode 1 = Copy function is active

This is only a selection from the Yaskawa manual YEG-SIEP C7 10606 27c of the screens mostly in use and does not demand any requirements for completeness.

R3 Mostly used standard-parameter II

R1 Mostly used standard-parameter I

Parameter Number:	Range min. max.	Default Setting Value:	Change during operation	Parameter-description
Language selection	A1-00 0 6 2 N	0=English; 2=German; 3=French 4=Italian; 5=Spanish; 6=Portugese		Determines the language selection of the LCD-Display of the V1000.
Parameter access level	A1-01 0 2 2 N	0 = Read only (Apart from A1-01; A1-04) 1 = Only user parameter A2-01 to A2-32 2 = Read and write access for all parameter.		Determines parameter access for the user:
Select control mode	A1-02 0 3 2 N	0 = V/Hz control 2 = OLV Open loop vector control 5 = PM Open loop vector control		Selects the motor control mode
Initialization	A1-03 0 333 0 N	0 = No Initialization 1110 = Init. User Parameter 2220 = Init. Default values (2-Wire) 3330 = Init. 3-wire Control		Sets the A1000 back to default values:
Reference source selection	B1-01 0 5 5 N	0 = Digital operator 1 = Analogue inputs via terminals 2 = Serial Communication 3 = Option PCB; 5 = CASE-Software		Determines the reference source:
RUN Command selection	B1-02 0 5 5 N	0 = Digital Operator 1 = >Digital inputs via terminals 2 = Serial Communication 3 = Option PCB; 5 = CASE-Software		Determines source for the RUN command:
Stop-command selection	B1-03 0 3 1 N	0 = Stop with ramp rate C1-01 1 = Spin Stop 2 = DC-Braking to stop 3 = Coast with timer		Determines the stopping method:
Reverse operation lock	B1-04 0 3 0 N	0 = Reverse mode enable 1 = Reverse mode disabled		Permits or prohibits reverse operation mode:
PID-function setting	B5-01 0 3 1 N	0 = PID disabled 1 = PID Active		
Proportional gain setting	B5-02 00 250 3 J	Caution: A too high gain may cause instability in the system. A too low value may increase the PID error..		Sets the proportional gain of the PID loop.
Integrationszeit	B5-03 00 360 2 J	Caution: A too short time may cause instability in the system. A too slow time may increase the PID error.		Sets the integral time of the PID loop.
PID-Output level selection.	B5-09 0 1 1 N	0 = normal --> Decreasing feedback will increase output signal. 1 = Invers --> Increasing feedback will increase output signal.		Sets the output direction:
Acceleration time in seconds	E1-01 00 600 30 J	Determines the acceleration ramp rate after receipt of a start signal from 0Hz to max speed according to parameter E1-04; Default: 60Hz		
Deceleration in seconds	E1-02 00 600 30 J	Determines the deceleration ramp rate after receipt of a stop signal from max. frequency to 0Hz according to parameter E1-04; Default: 60Hz		
Carrier frequency	E6-02 0 F 1 N	Default values are depending on the size of the A1000: 0=Low carrier frequency mode 1=2,0kHz; 2=5kHz; 3=8,0kHz; 4=10,0kHz; 5=12,5kHz; 6=15,0kHz; F=Free programm.		
Fixed speed D1-01 to D1-16	D1-01 0 600 00 J	There are up to 16 multi step frequencies which can be set via the terminals S3 to S6. D1-16 determines the frequency once the feedback pressure reference gets lost. Default: 30 Hz.		
Jog frequency reference	D1-17 0 600 60 J	The JOG frequency has got priority against other frequency references. Needs a digital input to be active parameter h1-XX in mode "6".		
Upper frequency limit	D2-01 0 110 100 N	Sets the upper limit of the output frequency as a percentage of the max. output frequency according to E1-04.		
Lower frequency limit	D2-02 0 110 50 N	Sets the limit limit of the output frequency as a percentage of the max. output frequency according to E1-04.		
Maximum output frequenz	E1-04 40 400 600 N	Determines the max. output frequency of the connected motor. The following conditions must be fulfilled: E1-04 => E1-06 => E1-07 => E1-09		
Max. ouput voltage	E1-05 0 510 400 N	Determines the max. output voltage and is needed to adjust the V/Hz curve of the connected motor/Compressor. See: E1-06 and E1-13		

This is only a selection from the Yaskawa manual YEG-SIEP C7 10606 27c of the screens mostly in use and does not demand any requirements for completeness.

R1 Mostly used standard-parameter I

Compressor Feedback

L8.1


In case several compressors are used in one rack, controlled by the A1000 it is possible to get a feedback from each individual compressor via the digital inputs. The A1000 will not activate any compressors which indicate a fault any more and pass on a message via digital output.

	Fault Compressor 1 running at the A1000	N	The input S8 will be used as a feedback from the speed controlled compressor once parameter h1-08 is set to mode "83". This unit will de-activated the compound controller keeps on working with the DOL units. Fault message via fault Relay.
	Fault Compound Compressor 2	N	The input S7 will be used as a feedback from compressor no 2. once parameter h1-07 is set to mode "84". This unit will de-activated the compound controller keeps on working with other DOL units. Fault message via fault Relay.
	Fault Compound Compressor 3	N	The input S6 will be used as a feedback from compressor no 3. once parameter h1-06 is set to mode "85". This unit will de-activated the compound controller keeps on working with other DOL units. Fault message via fault Relay.
	Fault Compound Compressor 4	N	The input S5 will be used as a feedback from compressor no 4. once parameter h1-06 is set to mode "86". This unit will de-activated the compound controller keeps on working with other DOL units. Fault message via fault Relay.

Example: Compressor fault message


L8.2

Compound controller with one speed controlled compressor and 2 units DOL (Direct on Line). Fault messages are failure-safe. This means that the inputs are active while the system is working failure free and not active in case of a fault. In every case the input signal must not have potential, just a relay contact. The direct connection of pressure switches is not recommended as these contacts are normally not designed to be used with control voltages.



Compound Controller with one speed controlled compressor and 2 compressors switched ON and OFF by the A1000 via contactor. Every compressor has got an internal motor protection device and a high pressure switch. The fault message will be activated via a relay contact o the digital input.

Example: Wiring for a fault message circuit of compressor no 1.



Parameter:
h1-08 =83 Terminal S8 (Fault speed controlled compressor)
h1-07 =84 Terminal S7 (Fault compressor 1)
h1-06 =85 Terminal S6 (Fault compressor 2)

Function:

- + Only in case all 3 inputs (S6, S7 and S8) are active, all 3 compressors will controlled by the A1000.
- + Once one input is not active, the A1000 recognizes this particular compressor due to the fault condition at the digital input.
- + Error message "CMPd (Compressor Fault)" occurs on the display.
- + If one of these inputs is programmed in mode 83 to 86, this input must get a signal.
- + In case the fault status disappears the A1000 starts again to use this compressor in the compound circuit.

Feedback Compressors


L8

L9.1 Speed control of the condensing fan 0-10V

In case a pressure transducer is giving feedback signal of the condensing pressure through analogue input A3 (0-10V), an internal PI controller creates an 0-10V signal to control the speed of a condenser fan via the 0-10V and the FM output. Only if the fan is capable to work with a 0-10V reference signal. (e.g.: EC-fan).

-PRMSET- Cond.Min. Press P6-01 = 0.0 Bar (-100.0-100.0) "0.0 Bar"	Lower level Sensor Condensing Unit	N	The condensing pressure will be measured through the analogue input A3, it must be a 0-10V signal. The parameter P6-01 and P6-02 determine the range of the pressure transducer. These settings are the reference to show the system pressure in real values on the display. Additionally they are the basis for an internal PI controller to create a 0-10 (4-20mA) signal for the condenser fan via the analogue output FM.
-PRMSET- Cond.Max. Press P6-02 = 30.0 Bar (-100.0-100.0) "30.0 Bar"	Upper level Sensor Condensing Unit	N	
-PRMSET- Cond.Ref. Press P6-03 = 12.0 Bar (-100.0-100.0) "12.0 Bar"	Reference Pressure Condenser	Y	
-PRMSET- P-Gain P6-04 = 5.0 (0.0-50.0) "5.0"	P-Gain Condenser	Y	
-PRMSET- I-Time P6-05 = 5.0sec (0.0-50.0) "5.0sec"	I-Time Condenser	Y	
-PRMSET- Level Cond.OFF P6-12 = 5.0bar (-50.0-50.0) "5.0bar"	OFF level Condensing Pressure	Y	
-PRMSET- Level Kond.hys P6-13 = 5.0bar (0.0-50.0) "5.0bar"	ON level Condensing Pressure (Hysteresis)	N	
-PRMSET- K1.A3 Funct Sel H3-06 = 22 Additional Ref 1 "2"	Function Analogue- input A3	N	
-PRMSET- K1.FM Funct Sel H4-01 = 707 Fan Volt. "102"	Function Analogue- output FM	N	
-MONITR- Kond. Druck U7-06 = 9.5 Bar U7-07 = 0.0% U7-08 = 0h	Monitor Condensing Pressure	N	

L9.2 Wiring Example condenser control



Speed control of a condensing unit; R134A; 10,0 Bar pressure.
 Sensor 2: Transducer 0,0 Bar to 18 Bar connected at A3 (Condenser pressure)
 P6-01 = 0,0 Bar (Lower value pressure transducer, Cond. pressure)
 P6-02 = 18,0 Bar (Upper value pressure transducer, Cond. pressure)
 P6-03 = 10,0 Bar (Reference pressure condenser)
 P6-05 = 5,0 (P-gain PI control)
 P6-06 = 10s (I-time PI control)
Function:
 + Once the condensing pressure exceeds the value set in parameter P6-03, the PI controller will increase the output speed of the condensing fan via the analogue output FM and a 0-10V signal.

L9 Speed control condenser fan

Checklist Commissioning

L14

Remark: L14.1

The following check list does not require any demand for completeness. The commissioning expert is responsible to meeting the local norms and standards.

Procedure: L14.2

+ Type: CIMR-

+ Serial number:

+ Fuse: A

+ Cable: mm²

+ Voltage: V

Prüfen des Verdichters: L14.3

+ Manufacturer:

+ Max. current:

+ Refrigerant: A

+ Evaporation temperature:

+ Suction pressure: °C

Bar

Check pressure transducer: L14.4


+ Manufacturer:

+ Type:

+ Range:

+ Connection:

Check connection of the pressure transducer. The transducer must be suitable for a supply voltage of von 10V/DC; 20mA.



Status message after .power ON: L14.5



The actual suction pressure will be displayed after power ON, in accordance with the manual.



In case the pressure transducer is not or wrong connected this message appears on the display.

Checklist Commissioning

L14

L13 Programming example

Change the reference for the suction pressure in parameter P1-03 from 3,0Bar to 4,0 Bar
 Press button until message in red characters will be displayed.:

L13 Handling and Programming


Load reduction due to High Pressure

L10.1

-PRMSET- PRG Kond.min.prssr P6-01 = 0.0 Bar (-100.0-100.0) "0.0 Bar" FWD	Lower level Sensor Condensing Pressure	N	The condensing pressure will be measured through the analogue input A3, it must be a 0-10V signal. The parameter P6-01 and P6-02 determine the range of the pressure transducer. These settings are the reference to measure the condensing pressure and in case it exceeds a certain value this function can be used to reduce the output power to avoid HP tripping of the circuitry.
-PRMSET- PRG Kond.max.Druck P6-02 = 30.0 Bar (-100.0-100.0) "30.0 Bar" FWD	Upper level Sensor Condensing Pressure	N	
-PRMSET- PRG HP max. level P6-06 = 22.0 Bar (-100.0-100.0) "22.0 Bar" FWD	Load reduction; Pressure Level; 0=OFF	Y	Once the condensing pressure has exceeded the value in parameter P6-06 for the time set in parameter P6-07 the A1000 will automatically reduce the output frequency to lower the output power.
-PRMSET- PRG HP - Time P6-07 = 10 sec (0-500) "10 sec" FWD	Time for Load reduction	Y	
-PRMSET- PRG HD - Speed P6-08 = 0045.0Hz (30.0-60.0) "45.0Hz" FWD	Frequency Load reduction	Y	Determines the output frequency of the A1000 once the pressure has exceeded the value set in parameter P6-06 for the time set in parameter P6-07. Therefore it reduces the power and the condensing pressure returns to normal values.
-PRMSET- PRG HP recover level P6-09 = 16.0 Bar (-100.0-100.0) "16.0 Bar" FWD	High Pressure Recovey level	N	Once the condensing pressure returns to a level below the value set in P6-09 for the time in P6-10 the A1000 will return to normal conditions. Exp.: P6-06 = 20.0 Bar; P6-07 = 20s; P6-08 = 45Hz; P6-09 = 16.0Bar; P6-10 = 10s.
-PRMSET- PRG HP - Time 2 P6-10 = 30 sec (0-500) "30 sec" FWD	Time for ecovery	N	Load reduction sequence will be terminated in case the pressure will come down below 16.0Bar for 10s.

Connection example: Load Reduction Circuit

L10.2



Start/Stop Variable Speed Drive via Input S1

Determines the evaporation pressure via pressure transducer connected to analogue input A2
 Signal: 4-20mA

Determines the condensing pressure via pressure transducer connected to analogue input A1
 Signal: 0-10V

Compressor control with mit R134A; 1,0 Bar Evaporation pressure.
 Load reduction at a condensing pressure of above 25.0Bar
 Load reduction is finished once condensing pressure drops below 20.0Bar condensing pressure. Load reduction to 75% of nominal compressor power.

Settings:

Sensor1: Pressure transducer -0,8 Bar to 7.0 Bar at A2 (Evaporation pressure)

Sensor2: Pressure transducer 0,0 Bar to 30.0 Bar at A3 (Condensing pressure)

Parameter:

P1-01 = -0,8 Bar (Lower limit transducer, Evaporation pressure)

P1-02 = +7,0 Bar (Upper limit transducer, Evaporation pressure)

P1-03 = 1,0 Bar (Pressure reference)

P6-01 = 0,0 Bar (Lower limit transducer, Condensing pressure)

P6-02 = 30,0Bar (Upper limit transducer, Condensing pressure)

P6-06 = 25,0Bar (Pressure level to reduce load)

P6-07 = 20s (Min. 20s above 25,0 Bar to activate this function.)

P6-08 = 45Hz (Fixed speed to reduce load; fmax=60Hz)

P6-09 = 20,0Bar (Pressure to return to normal settings)

Function:

+ Once the condensing pressure exceeds for min. 20 seconds a value of 25.0Bar, the output speed will be reduced, to lower output power.

+ The PID loop to control the evaporation pressure will be not active, output speed remains at 45Hz.

+ In case the condensing pressure falls below the value set in parameter P6-09 the PID loop to control the evaporation pressure gets active again.

Peak-load dropping function

L10

<p>-PRMSET- PRG Min. pressure P1-01 = -0.8 Bar (-100.0-100.0) "0.8 Bar"</p>	<p>Description Parameter Number Range Default setting</p>	<p>Changable during RUN. Values in "RED" differ from default. Parameter-Description</p>
<p>-PRMSET- PRG Emergency P2-10 = 1 Enable "0"</p>	<p>Notlaufmodus EIN</p>	<p>In case the speed controlled compressor trips during run, the A1000 may be capable to control the DOL compressors further, depending on the fault. Mode 0: A1000 to trip; 1: Emergency active</p>
<p>-PRMSET- PRG Feedb. loss spd. P3-04 = 0045.0Hz (30.0-60.0) "45.0Hz"</p>	<p>Frequenz bei Signalverlust</p>	<p>In case the pressure transducer to meausure is not connected or broken, the A1000 will change to a fixed speed set in this parameter. A message occurs: „Freq without FB“.</p>

Function of the LCD Text Display

L12.1

Line 1
TOP LEFT "MONITR"
The V1000 is now in Monitor mode.

Line 2
Parameter text description
Pressing keys

Line 3
TOP RIGHT Status:
Rdy = Ready

Line 5
Shows frequency reference

Line 6
Shows output frequency

Shows output current
Pressing **ENTER** key gives access to the submenus:

- > Monitoring menu
- > Access to monitor display
- > Access to modified constants
- > Access to basic parameters
- > Access to all parameters
- > Access to Autotunig menu

RESET - Key
Moves cursor to the right, selects digit and is used as RESET-key.

ENTER - Key
Gives access to all submenus and confirms data input after pressing key.

ESC - Key
Returns to previous menu, before **ENTER** was pressed.

LOCAL/REMOTE - Key
Local: Bedienfeldsteuerung
Remote: Klemmensteuerung

Pressing **UP** - Key or **DOWN** - key selects parameter and increases or decreases values

F1 and F2 - Key
Additional function keys with different functions.

RUN - Key
Starts the frequency inverter via display

STOP - Key
Stops the frequency inverter via display