



PED Software

Installationsanleitung

Unpack and Connect:

Required Hardware:

Step 1: Unpack
USB-RS232 Converter
RJ45 – Cable
Adapter



Step 3:
Link V1000 and PC

or

Step 2: Connect



Step 3:
Link A1000 and PC

Remarks:

- 1) First boot your PC
- 2) Install Software according to the guideline
- 3) Switch on the inverter after all parts were correctly linked with each other
- 4) All legal standards should be considered in order to use all components as per their specification